



! INFO !

Do not charge the battery of the towing vehicle and/or towed vehicle directly via the socket.



User guide




SPARE PARTS

www.ecs-electronicsuk.co.uk



Partnr.: MB-074-D1U

User Guide




Mercedes Benz E Class









W211 03/2002-04/2009
S211 03/2003-04/2009

Mercedes Benz C Class




Class W203 06/2000-
Class C203 03/2001-
Class S203 03/2001-
Class CL203 06/2008-
Class C209 05/2002-
Class A209 05/2003-



INFO



CHANGING THE FUSE



SOCKET CONNECTION


DIN/ISO 11446	↶	⚡	1-8	↷	☀	STOP	☀	Reversion	30+ 15+	15+	10	—	9
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8	9	10	11	12	13
Pmax	21W	2x21W		21W	52W	3x21W	52W	2x21W	180W/15Amp	180W/15Amp			
Colour	Yellow	Blue	White	Green	Brown	Red 1,00 mm ²	Black	Black/ Red	Brown/ White	Red 2,50 mm ²	White	-	White






In a coupled trailer with working fog lamp, the fog lamp of the vehicle will be switched off, if applicable.




The flashing lights on the trailer are monitored. If one of the indicators of the trailer breaks down, a buzzer will be audible and/or a visual signal will be visible on the dashboard. Check the flashing lights on the trailer.







INFO : Ring.







INFO



INFO : Adapt.



INFO



INFO : Storage

