
## ! INFO!


Do not charge the battery of the towing vehicle and/or towed vehicle directly via the socket.






**SPARE PARTS** 


www.ecs-electronicsuk.co.uk



© ECS Electronics B.V. www.ecs-electronicsuk.co.uk FR-028-BLU / 020216TT © ECS Electronics B.V. www.ecs-electronicsuk.co.uk Revision: 0 FR-028-BLU / 020216TT



© ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 2 FR-028-BLU / 020216TT © ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 7 FR-028-BLU / 020216TT




© ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 6 FR-028-BLU / 020216TT © ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 3 FR-028-BLU / 020216TT

## INFO

## **SOCKET CONNECTION**

DIN/ISO	<b>\( \rightarrow</b>	<b>◆</b> ()≢	<u>-</u> 1-7	$\Rightarrow$	-¦Ç-	STOP	-¦Ö҉-
1724	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	2x21W		21W	52W	3x21W	52W
Colour	Yellow	Blue	White	Green	Brown	Red	Black



In a coupled trailer with working fog lamp, the fog lamp of the vehicle will be switched off, if applicable.





The flashing lights on the trailer are monitored. If one of the indicators of the trailer breaks down, a buzzer will be audible and/or a visual signal will be visible on the dashboard. Check the flashing lights on the trailer.

## CHANGING THE FUSE

© ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 4 FR-028-BLU / 020216TT © ECS Electronics B.V. www.ecs-electronicsuk.co.uk Pag. 5 FR-028-BLU / 020216TT