


**Seat Leon Limo 5D & 3D 2013 - 05/2014**  
**Seat Leon ST 2013 - 05/2014**

Only for models without towbar prepared connector








Partnr.: AU-046-B1U








- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:  
[ukts@ecs-electronics.com](mailto:ukts@ecs-electronics.com) / 07440 202 052.




# Part list




\* Reverse signal preparation




Leon Limo






Leon ST




1




2




3




4



5




6




# Léon Limo

7




8




# Léon ST


9




10






11




12




13




**A** Option 1



Option 2



Option 3





**INFO**





SOCKET CONNECTION



Pag. 15




**B** Option 1









16





17



18




19









20




21



22




23



24


1

BCM-A




2

BCM-A




3

BCM-A




25

BCM-A




26

BCM-A




27

BCM-A




28

1




BCM-A

2



BCM-A


3



BCM-A


29

1




BCM-C

2



BCM-C


3



BCM-C


30

BCM-C




31

BCM-C




32

BCM-C




33

1




BCM-C

2




BCM-C



3



BCM-C






34





3



7




35




36



2




37



INFO

## ONLINE CODING



**INFO**

Warning! It must be ensured that all the requirements of the vehicle manufacturer for changes to and retro-fitting on the vehicle and/or cooling system for the operation with a trailer are carried out. Subject to change.

**38**




TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

**INFO**

REINSTALL TRIM.

**39**



**INFO**


SOCKET CONNECTION

DIN/ISO 1724							
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	21W		21W	42W	3x21W	42W
Colour	Black/White	Blue	Brown	Black/Green	Grey/Red	Black/Red	Grey/Black




# Reverse signal preparation


A




1



2



B



⚠ MAX = 21W

