



Ford Kuga II 03/2013 >> 01/2020

Partnr.: FR-060-B1U

- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
ukts@ecs-electronics.com / 07440 202 052.



Part list




L1


L3



L2




M



X



G




T




M




1x



1x



15x



X

UN-243-YZ


Optional reverse lamp pre-wire extension included



Pag. 10




3x




1x


20 Amp.




6x




3x




1x




1







2







3





4







5



Option 1




2pole Grey




5pole Green




Option 2



2pole Grey




4pole Black




6

Option 1




1



5pole Green


L2

2



7

Option 2




2pole Grey



L1

1


4pole Black



L2




2





Brown	→	Grey/Orange
Green	→	Purple/Orange
Blue/Red	→	Black/Blue


3




8





9




1





2






3




4




10







11



12



13



14




TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO



REINSTALL TRIM.

15



INFO

Products & Service



http://www.ecs-electronics.nl/NL/catalogus/test_gereedschap


INFO

SOCKET CONNECTION


DIN/ISO 1724							
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	21W		21W	42W	3x21W	42W
Colour	Yellow	Blue	White	Green	Brown	Red	Black

UN-243-YZ Reverse lamp pre-wire extension


⚠ MAX = 21W




A




1




2




3



4



5



B

⚠ MAX = 21W

