



Ford Transit Connect 01/2014 >>

Partnr.: FR-065-D1U


- Fitting instructions electric wiring kit tow bar with 13-P socket up to DIN/ISO Norm 11446.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
ukts@ecs-electronics.com / 07440 202 052.



Part list



M




L1




L3




L2




X




G





M



X




T



15x




3x




1x


20 Amp.



2x




3x




1x


15 Amp.






6x







1



2




3




A


Option 1



Option 2





Option 3




SOCKET CONNECTION

B Option 1




C Option 2


1




2



3




4




D Option 3


1




2




3




4





Remove tape.



Option 1





Option 2




Supplier
FR-060-ZZ

Option 3




Supplier
FR-050-ZZ


5



Option 1




2pole Grey




5pole Green




Option 2



2pole Grey




4pole Black



6


Option 1



2pole Grey

L1


1



5pole Green


L2

2



7

Option 2



2pole Grey



L1

1

2

4pole Black


L2




3




Brown	→	Grey/Orange
Green	→	Purple/Orange
Blue/Red	→	Black/Blue




8




9




10






11




12



13



C2



14




TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO

REINSTALL TRIM.

15



INFO

SOCKET CONNECTION

DIN/ISO 11446													
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8	9	10	11	12	13
Pmax	21W	21W		21W	42W	3x21W	42W	21W	180W/15Amp	180W/15Amp			
Colour	Yellow	Blue	White	Green	Brown	Red 1,00 mm ²	Black	Black/ Red	Brown/ White	Red 2,50 mm ²	White	-	White