


**Nissan X-trail 10/2007-
Nissan Qashqai 2007-
Nissan Qashqai+2 2008-**


Partnr.: NI-041-BHU



- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
t.skinner@ecs-electronics.com / 07440 202 052.




Part list




ROUTING


X-trail




Qashqai & Qashqai+2




1






X-trail

3




Qashqai

4




Qashqai+2

5





X-trail

6



Qashqai & Qashqai+2


7




X-trail & Qashqai & Qashqai+2

A


Option 1



Option 2



Option 3



INFO



SOCKET CONNECTION



Pag. 12

B


Option 1




X-trail & Qashqai & Qashqai+2

C


Option 2



②




③




D


Option 3



②






③




X-trail

8






9





1 Qashqai & Qashqai+2


2 Qashqai




2 Qashqai+2



Qashqai & Qashqai+2






Qashqai & Qashqai+2




X-trail

10



11


X-trail



1






X-trail	Qashqai
Orange	Yellow




2

Qashqai & Qashqai+2





3




Qashqai & Qashqai+2


12



Qashqai




Qashqai+2



X-trail & Qashqai & Qashqai+2


13



TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO


REINSTALL TRIM.



User guide



Products & Service






http://www.ecs-electronics.nl/NL/catalogus/test_gereedschap



INFO


SOCKET CONNECTION

DIN/ISO 1724							
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	2x21W		21W	52W	3x21W	52W
Colour	Yellow	Blue	White	Green	Brown	Red	Black




UN-243-YZ Reverse lamp pre-wire extension


⚠ MAX = 21W




A




1




2




3



4



5



B

⚠ MAX = 21W

