

Peugeot 508 Sedan (W2) 01/2011-Peugeot 508 SW (W2) 01/2011-Peugeot 508 RXH (W2) 04/2012-



- Fitting instructions electric wiring kit tow bar with 13-P socket up to DIN/ISO Norm 11446.
- We would expressly point out that assembly not carried out properly by a competent installer will resultin cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.


• Do not overload circuits; the maximum loads per connection are detailed in this manual.

- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:


t.skinner@ecs-electronics.com / 07440 202 052.




## Part list




© ECS Electronics B.V. Pag. 2 PE-061-D1U / 070116TT







© ECS Electronics B.V. Pag. 3 PE-061-D1U / 070116TT




© ECS Electronics B.V. Pag. 4 PE-061-D1U / 070116TT


## 508 SW & 508 RXH







© ECS Electronics B.V. Pag. 5 PE-061-D1U / 070116TT













© ECS Electronics B.V. Pag. 6 PE-061-D1U / 070116TT













© ECS Electronics B.V. Pag. 7 PE-061-D1U / 070116TT







© ECS Electronics B.V. Pag. 8 PE-061-D1U / 070116TT







© ECS Electronics B.V. Pag. 9 PE-061-D1U / 070116TT







© ECS Electronics B.V. Pag. 10 PE-061-D1U / 070116TT




15

TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

THIS PURPOS

INFO

REINSTALL TRIM.





© ECS Electronics B.V. Pag. 11 PE-061-D1U / 070116TT

## **SOCKET CONNECTION**

DIN/IS		<b>◆</b> ()≢	<u></u> 1-8	$\Rightarrow$	-\̈́\-	STOP		Reverse 0=	30+	15 <b>9 L</b>	<u></u> 10		<u></u> 9
11446	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8	9	10	11	12	13
Pmax	21W	21W		21W	42W	3x21W	42W	21W	180W/15Amp	180W/15Amp			
Colou	Yellow	Blue	White	Green	Brown	Red 1,00 mm <sup>2</sup>	Black	Black/ Red	Brown/ White	Red 2,50 mm <sup>2</sup>	White	-	White

© ECS Electronics B.V. Pag. 12 PE-061-D1U / 070116TT