


Seat Alhambra 2011- Volkswagen Sharan 2011-

Partnr.: SE-037-B1U

- Fitting instructions electric wiring kit tow bar with 12-N socket up to DIN/ISO Norm 1724.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
t.skinner@ecs-electronics.com / 07440 202 052.



Part list






L2




L1



L3





X




* Reverse signal preparation




Pag. 11





20 Amp.









1



2




3




A


Option 1



Option 2




Option 3



INFO


SOCKET CONNECTION




Pag. 11

B

Option 1







C

Option 2


1



2




3




D

Option 3


1



2




3





4


1





2






3





4




5




6




7




8




9




10




11







12




13





16



17

A VAG Service Tester must be used to code the vehicle's Gateway with the additional function for the towing hitch at the dealer.


18

! TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO

REINSTALL TRIM.








19



User guide







SOCKET CONNECTION

DIN/ISO 1724			 1-7				
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L
Pmax	21W	21W		21W	42W	3x21W	42W
Colour	Black/ White	Blue	Brown	Black/ Green	Grey/ Red	Black/ Red	Grey/ Black

Reverse signal preparation

A

1

2

B


 MAX = 21W

