





Mercedes Benz C Klasse

S204 (wagon) 09/2007-
W204 (sedan) 03/2007-
C204 (coupé) 04/2011-
X218 (shooting brake) 10/2012-




Mercedes Benz E Klasse

S212 (wagon) 11/2009-
W212 (sedan) 04/2009-
C207 (coupé) 05/2009-
A207 (cabrio) 03/2010-



Mercedes Benz GLK

X204 (SUV) 11/2008-














Partnr.: MB-076-D1U

- Fitting instructions electric wiring kit tow bar with 13-P socket up to DIN/ISO Norm 11446.
- We would expressly point out that assembly not carried out properly by a competent installer will result in cancellation of any right to damage compensation, in particular those arising by virtue of the product liability act.
- Contents of these kits and their fitting manuals are subject to alteration without notice, please ensure that these instructions are read and fully understood before commencing installation.
- Do not overload circuits; the maximum loads per connection are detailed in this manual.
- Attention! Before Installation, please read this manual carefully and inform your customer to consult the vehicle owners manual to check for any vehicle modifications required before towing.
- In the event of functional problems, troubleshooting must be limited to about 0.5 hours, contact the technical support:
t.skinner@ecs-electronics.com / 07440 202 052.





Part list



INFO



Pag. 5



Chassis Number:

F 0106397 > 31.05.2007

R 000150 > 28.06.2007



A 027946 > 31.05.2007




Potential Change
Of SAM Module







INFO




SAM Module






C KLASSE LIMOUSINE & COUPÉ

ROUTING




C KLASSE ESTATE / CLS SHOOTING BRAKE

ROUTING




E KLASSE LIMOUSINE

ROUTING




E KLASSE COUPÉ & CABRIO

ROUTING




E KLASSE ESTATE

ROUTING




GLK

ROUTING




C KLASSE LIMOUSINE & COUPÉ / E KLASSE LIMOUSINE & COUPÉ & CABRIO

2




C KLASSE ESTATE / E KLASSE ESTATE / CLS SHOOTING BRAKE

3




4






C KLASSE LIMOUSINE & ESTATE & COUPÉ / CLS SHOOTING BRAKE

5





E KLASSE LIMOUSINE & COUPÉ & ESTATE & CABRIO

6



GLK


7




ALL MODELS

A

Option 1



Option 2



INFO

SOCKET CONNECTION




Pag. 17

ALL MODELS


B

Option 1




C

Option 2




C KLASSE ALL MODELS / E KLASSE ALL MODELS / CLS SHOOTING BRAKE


8



OPTION 1













9




OPTION 2




IF PIN 9 Brown & PIN 10 Brown/Red ARE TAKEN




10




OPTION 3




1




2




3




4




5







6



7








11




ALL MODELS

12




C KLASSE LIMOUSINE & ESTATE & COUPÉ / CLS SHOOTING BRAKE

13




E KLASSE LIMOUSINE & COUPÉ & ESTATE & CABRIO

14




GLK


15




16



17






18






19




20




21



22






23





INFO

Manual PDC



Auto PDC



24




TEST ALL THE CIRCUITS WITH A TEST DEVICE WITH THE CORRECT POWER LOAD FOR EACH FUNCTION. A TEST DEVICE WITH LED'S CANNOT BE USED FOR THIS PURPOSE.

INFO

REINSTALL TRIM.

25



User guide

TECHNICAL SUPPORT














CALL 07440 202 052

MONDAY TO FRIDAY
08.00 - 11.00 am
12.00 - 05.00 pm

t.skinner@ecs-electronics.com
www.ecs-electronicsuk.co.uk

ECS ELECTRONICS

SOCKET CONNECTION

DIN/ISO 11446													
	1/L	2	3/31	4/R	5/58-R	6/54	7/58-L	8	9	10	11	12	13
Pmax	21W	2x21W		21W	52W	3x21W	52W	2x21W	180W/15Amp	180W/15Amp			
Colour	Yellow	Blue	White	Green	Brown	Red 1,00 mm ²	Black	Black/ Red	Brown/ White	Red 2,50 mm ²	White	-	White